

# **User** Manual

Three phase LV Hybrid Inverter

Isuna D5~12K-TL

The state of the s



Shenzhen Sinexcel Isuna
Energy Technology Co.,LTD

V1.2

# Catalogue

1.C	verview	1
	1.1 Scope of Application	1
	1.2 Applicable Personnel	1
	1.3 Symbol Definition	1
2. 8	Safety Precautions	2
	2.1 Operation Safety	2
	2.2 PV String Safety	3
	2.3 Battery Safety	3
	2.4 Inverter Safety	4
	2.5 Personnel Requirements	4
	2.6 Description of Symbols	5
3.E	quipment Inspection and Storage	6
	3.1 Pre-signing Inspection	6
	3.2 Packing List	6
	3.3 Equipment Storage	9
4.P	roduct Description	9
	4.1 Product Overview	9
	4.2 Application Scenario	10
	4.3 Appearance Description	11
	4.3.1 Appearance Description	11
	4.3.2 Size Description	13
5 Ir	nstallation	14
	5.1 Installation Requirements	14
	5.1.1 Installation Environment Requirements	14
	5.1.2 Mounting Carrier Requirements	15
	5.1.3 Mounting Angle Requirements	15
	5.2 Mounting Tools	17
	5.3 Inverter Transportation	19
	5.4 Wall Mounted	20

6. Electrical Connection	22
6.1 Electrical System Connection Diagram	22
6.2 External Port Wiring Instructions	24
6.3 Connecting the Ground Cable (PE)	26
6.4 Connecting the PV Cable and the Battery Cable	27
6.5 Connect battery cable	30
6.6 Connect AC Load/grid/Diesel generator Cable	31
6.7 Installation of Communication Dongle	32
6.8 Connecting the Communication Port	34
6.8.1 Smart Meter Connection	36
6.8.2 BMS Communication Connection	38
6.8.3 DRMS/DI Connection	39
6.8.4 Paralleling	40
7 Inverter Operation	44
7.1 Pre-power-on Inspection	44
7.2 Initial Power-on	44
7.3 Working Mode	45
7.3.1 Self-use Mode (default mode)	45
7.3.2 Timed Charge/Discharge Mode	46
7.3.3 Backup Mode/Disaster Recovery Mode	49
7.3.4 Priority Feed to Grid Mode	50
7.4 Operation Mode	51
7.4.1 Operation Mode Description	51
7.4.2 Indicator Light Description	52
8 App Introduction	55
9. Troubleshooting and Maintenance	56
9.1 Alarm and Processing	56
9.2 Regular maintenance	62
10. Technical Parameters	63

# 1.Overview

This document describes the product information, installation, electrical connection, configuration and commissioning, troubleshooting and maintenance, and technical specifications of the three phase hybrid inverter. Before installing and using the product, read this manual carefully to familiarize yourself with the safety information and functions and features of the product. Manuals may be updated from time to time, please obtain the latest version from the official website for more product information.

# 1.1 Scope of Application

This manual is applicable to the following inverters:

Model	Rate output power	Rated output voltage		
Isuna D5K-TL	5000W			
Isuna D6K-TL	6000W			
Isuna D8K-TL	8000W	3L/N/PE,220/380Vac,		
Isuna D10K-TL	10000W	230/400Vac		
Isuna D12K-TL	12000W			

Note: Since the product will be overload protected at an ambient temperature above 40 °C, the high temperature mode test in the Italian Grid Specification certification will be carried out at an ambient temperature of 40 °C.

### 1.2 Applicable Personnel

This document is intended for only professional and technical personnel who are familiar with local regulations, standards, and electrical systems, and have professional training and knowledge about this product.

### 1.3 Symbol Definition

In order to ensure the personal and property safety of users when using three phase hybrid inverters, as well as the efficient use of this product, the manual provides relevant safe operation information and uses corresponding symbols to highlight. To avoid personal injury and property damage, please fully understand and absolutely comply with these stressed information. The symbols used in this manual are listed below.

# Danger

Indicates a highly hazardous situation which, if not avoided, will result in death or serious injury.

# ♠ Warning

Indicates a hazard with a medium level of risk that could result in death or serious injury if not avoided.

# Caution

Indicates a hazard with a low level of potential that, if not avoided, could result in moderate or minor injury.

# Attenion A

Indicates a potentially hazardous situation that, if not avoided, may cause equipment failure or property damage.

# 2. Safety Precautions

The safety precautions contained in this document must be followed when operating the device.

# Attenion

The inverter has been designed in strict accordance with safety regulations and has passed the tests. However, as an electrical device, you must comply with relevant safety instructions before performing any operation on the device. Improper operation may result in serious injury or property damage.

# 2.1 Operation Safety



# !\ Attenion

- Read this manual carefully before installing the device to understand the products and precautions.
- All operations on the equipment must be carried out by professional electrical technicians who are familiar with the local standards and safety regulations.
- ▶ When operating inverters, use insulation tools and wear personal protective equipment. Wear ESD gloves, an ESD wrist strap, and an ESD suit when touching electronic

components to prevent damage caused by static electricity.

The manufacturer shall not be liable for inverter damage or personal injury caused by failure to install, use, or configure the equipment in accordance with the requirements of this manual.

# 2.2 PV String Safety

# **A** Danger

Use the DC wiring terminal delivered with the chassis to connect the DC cables of the inverter. Use of other types of DC terminals may cause serious consequences.
Therefore, the manufacturer is not responsible for the damage to the device.

# Warning

- Ensure that the assembly frame is properly grounded to the support system.
- After connecting DC cables, ensure that the cables are securely connected.
- Use a multimeter to check whether the positive and negative DC wiring terminals of the battery are connected correctly and the voltage is within the allowable range.
- Do not connect the same PV series to multiple inverters; otherwise, the inverters will be damaged.

# 2.3 Battery Safety

# / Warning

- Read the battery safety contents in the user manual carefully before installing the device, and strictly follow the instructions in the user manual.
- The battery current may be affected by external environment, such as temperature and humidity, which may cause battery current limiting and affect battery on-load performance.
- If the battery does not start, contact the after-sales service center as soon as possible.
  Otherwise, the battery may be permanently damaged.
- > Use a multimeter to check whether the positive and negative DC wiring terminals of the battery are connected properly and the voltage is within the allowable range.
- Do not connect the same battery string to multiple inverters. Otherwise, the inverters may be damaged.

# 2.4 Inverter Safety

# Warning

- > Ensure that the voltage and frequency of the grid-connected access point comply with the inverter grid-connected specifications.
- A protection device, such as a circuit breaker or fuse, is recommended for the AC side of the inverter. Ensure that the protection device is greater than 1.25 times the maximum AC output current of the inverter.
- The GND cable for the inverters must be securely connected. When multiple inverters are combined, ensure that the protection ground points on all inverters' chassis shells are equipotential connected.
- If the battery is not configured in the photovoltaic system, it is not recommended to use the off-grid function, and the resulting system electricity risk will not be covered by the equipment manufacturer's warranty.

### 2.5 Personnel Requirements



When the inverter is running, some components may be charged or hot. Improper use, incorrect installation, or operation may result in serious injury to person or property. Transportation, loading, unloading, installation, starting and maintenance operations must be performed by qualified electrical engineers.

# 2.6 Description of Symbols

There are some safety-related labels on the three phase hybrid inverter. Please read and fully understand these labels before installing the product.

Symbol	Symbol name	Symbol meaning
5min	It indicates the danger of residual voltage in the inverter.	Please wait for 5 minutes until the capacitor is completely discharged after the DC side of the inverter has been disconnected with power for a period of time.
	It indicates the danger of high voltage.	High voltage exists during inverter operation. If you need to operate the inverter, please make sure the inverter is disconnected.
	It indicates to be careful of high temperature surface.	The temperature of inverter housing is high during operation, so do not touch it, otherwise it may cause burns.
	It indicates grounding terminal.	Connect the inverter to ground for grounding protection purpose.
i	It indicates reading the manual.	Please read and understand this manual carefully before installing the inverter.

# 3. Equipment Inspection and Storage

# 3.1 Pre-signing Inspection

Before signing for the product, please check the following:

- Check the outer packing for holes, distortions, cracks, or other signs that may cause damage to the equipment in the packing case. If so, do not open the packing and contact your distributor.
- Check whether the inverter type is correct. If not, do not open the package and contact your dealer.
- Check whether the type and quantity of the delivered package are correct and whether the appearance is damaged. If damaged, please contact your dealer.

# 3.2 Packing List

After the inverter is unpacked, check whether the delivered package are complete. If any components are found missing or incomplete, contact the dealer in time.

Table 3-1 Components and mechanical parts to be delivered

No.	photos	descriptions	quantity
1		Inverter	1 PCS
2		WIFI dongle (optional)	1 PCS
3		e-user manual	1 PCS
4		Certificate, Quality assurance card	1 PCS
5		Delivery inspection report	1 PCS

6	AC load terminal  AC grid terminal  AC generator terminal	3 PCS
7	Black 6.0mm² cable lugs (for load/grid/generator side wiring)	15 PCS
8	BAT input terminal protective cover	5 PCS
9	PV+ wire end input terminal plastic case	3 PCS
10	PV- wire end input terminal plastic case	3 PCS
11	PV-&BAT-wire end input terminal metal core	3 PCS
12	PV+&BAT+ wire end input terminal metal core	3 PCS

13	Wall-mounted rear cover	1 PCS
14	M8*80 expansion bolt	3 PCS
15	Waterproof cover	1 PCS
16	Cross recessed hexagon head combination screw M6*12	3 PCS
17	Smart meter	IPCS
18	CT (used with the meter)	3PCS
19	Meter communication line	1 PCS
20	BMS communication line	2 PCS

21		PV &BAT Disassembly wrench	1 PCS
22	Cal Cal	Desiccant	1 PCS

# 3.3 Equipment Storage

If the inverter is not put into use immediately, store it according to the following requirements:

- Ensure that the outer packing case is not removed and the desiccant is not lost.
- Ensure that the storage environment is clean and within appropriate temperature and humidity ranges.
- Ensure that inverters are placed in the height and direction according to the labels on the packing cases.
- Ensure that there is no tilt and fall risk after inverters are stacked.
- After the inverter is stored for a long time, check and confirm the inverter before it can be used.

# 4.Product Description

### 4.1 Product Overview

Three phase hybrid inverter is a photovoltaic grid-connected inverter and battery energy storage as one, with a variety of built-in working modes to suit the diversified needs of users. In the period of rising energy costs such as oil and coal, the continuous decline of energy subsidies for photovoltaic grid-connected systems, mountain areas or base stations without grid, uninterrupted power supply and emergency power supply needs, three phase hybrid inverters can provide a complete solution.

## 4.2 Application Scenario

### Warning

- The photovoltaic system is not suitable for devices that rely on stable power supply, such as life-sustaining medical devices. Ensure that no personal injury is caused when the system is powered off.
- Do not use a load with a high starting current in the photovoltaic system. Otherwise, the off-grid output may fail due to excessive instantaneous power.
- When the inverter overload protection occurs for a single time, the inverter can automatically restart; If it happens several times, the inverter will stop, and after the fault is rectified, the inverter can be restarted immediately through the App.
- If the load capacity exceeds the rated power of the inverter during power failure, the off-grid function of the inverter automatically shuts down. To start, turn off the large load and ensure that the load power is smaller than the rated power of the inverter.
- When the inverter is in off-grid mode, it can be used normally for ordinary household load.
- Inductive load: 1.5P non-variable frequency air conditioners are supported. The standby mode may be unstable if two or more non-variable frequency air conditioners are connected.
- ➤ Capacitive load: total power ≤0.7 x rated output power of inverter.

# 4.3 Appearance Description

# 4.3.1 Appearance Description




Figure 4.1 Illustration of the appearance of the inverter

# Table 4-1 Appearance of the inverter

1	Communication module interface	2	Waterproof and breathable device
3	WiFi/4G interface	4	Off-grid AC wiring port
5	Grid-connected AC wiring port	6	Generator-connected AC wiring port
7	PV DC input switch	8	PV DC input port (PV+/-)
9	Fan assembly	10	Battery DC input port (BAT+/-)

# 4.3.2 Size Description

Figure 4.2 Overall size of inverter




Figure 4.3 Dimensions of wall mount





Figure 4.3 Dimensions of wall mount

### 5 Installation

## 5.1 Installation Requirements

### 5.1.1 Installation Environment Requirements

- 1) The equipment must not be installed in flammable, explosive, corrosive and other environments.
- 2) The installation position should be away from water pipes and cables in the wall to avoid danger during drilling.
- 3) The installation position should be out of the reach of children, and avoid installation in a position that is easy to touch. There may be high temperature on the surface of the equipment during operation to prevent burns.
- 4) The inverter should avoid the installation environment such as sun, rain, snow, etc. It is recommended to install it in a sheltered installation position. If necessary, an awning can be built.
- 5) The installation space must meet the requirements of ventilation, heat dissipation and operation space.
- 6) The protection level of the equipment complies with the requirements for indoor and outdoor installation, and the installation environment temperature and humidity must be within the appropriate range.
- 7) Make sure that the inverter indicator light and all labels are easy to view and that the terminal is easy to operate.
- 8) The inverter installation altitude should lower than the maximum working altitude 4000m.
- 9) Stay away from strong magnetic field environment to avoid electromagnetic interference. If a radio station or a wireless communication device below 30MHz is located near the installation location, install the device according to the following requirements:
- Add a ferrite core with multi-turn winding at the inverter DC input line or AC output line, or add a low-pass EMI filter.
- The distance between the inverter and the wireless electromagnetic interference device exceeds 30m.




# 5.1.2 Mounting Carrier Requirements

- 1) The installation carrier must not be flammable material and must have fire resistance.
- 2) Please ensure that the installation carrier is solid and reliable, and can carry the weight of the inverter.
- 3) When the equipment is running, it will make noise. Do not install it on the carrier with poor sound insulation, so as to avoid the noise emitted by the equipment when it is working, which will cause trouble to residents in the living area.

### 5.1.3 Mounting Angle Requirements

- 1) Recommended inverter installation Angle: vertical or backward ≤15°.
- 2) Do not invert, tilt forward, tilt back beyond the Angle, horizontal installation.
- 3) At least 1.2m from the ground below the inverter, about at least 300mm.




# **5.2 Mounting Tools**

Table 5-1 List of installation tools

Table 5-1 List of illstallation tools					
Series No.	Tools	Description	Function		
1		Percussion drill Recommended 10mm drill	Wall drilling		
2	THE O	6mm cross-head screwdriver	Removing, installing screws and wiring		
3		4mm cross-head screwdriver	Removing and installing load、grid、generator terminal screws		
4		Removal tool	Removal of PV, line end terminals		
5	J.S.	Wire strippers	Stripping wire		
6		Crimping pliers	Crimping PV and BAT cables		

7	Crimping pliers	Pressure welding grid, load end cable
8	Multimeter	Check whether the cable wiring is correct, the positive and negative battery terminals are correct and voltage, and grounding is reliable
9	Marking pen	Drilling mark
10	Таре	Measurement distance
11	Protective gloves	Wear when setting up the inverter
12	Goggles	Wear when drilling holes
13	Dust mask	Wear when drilling holes

# 5.3 Inverter Transportation




# ! Caution


- When transporting, turning around, installing and other operations, it must comply with the laws and regulations and relevant standards of the country or region where it is located.
- > The inverter is heavy. Please keep it balanced during handling to prevent the inverter from falling and injuring the operator.
- The power cable and signal cable ports at the bottom of the inverter cannot bear any weight. Do not touch wiring terminals directly. Place the inverter horizontally.
- When the inverter is placed on the ground, put foam or paper under it to avoid damage to the shell.

# 5.4 Wall Mounted

# Attenion

- When drilling holes, ensure that the holes are drilled away from water pipes and cables Þ in the wall to avoid dangers.
- $\triangleright$ When drilling holes, wear goggles and a dust mask to prevent dust from inhaling into the respiratory tract or falling into the eyes.





### 6. Electrical Connection

Before installation and maintenance, ensure that the AC/DC side is not powered on. The capacitors are still powered on for a period of time after the inverter is powered off. Therefore, wait at least five minutes to ensure that the capacitors are fully discharged. Three phase hybrid inverters are used in battery energy storage photovoltaic systems. Equipment can be damaged if not used as intended.

# 6.1 Electrical System Connection Diagram



### Attenion

- Connect the N and PE cables to the ON-GRID and BACK-UP ports of the inverters in different regions according to local regulations. For details, see local regulations.
- > If the BACK-UP AC port is powered on after the inverter is started, power off the inverter to maintain the backup load. Otherwise, electric shocks may occur.
- Inverter ON-GRID and BACK-UP AC ports have built-in relays. When the inverter is in off-grid state, the built-in ON-GRID relay is in disconnected state; When the inverter is in the on-grid state, the built-in ON-GRID relay is in the closed state.

### NOTE:

- Recommended parameters for DC circuit breakers on the battery side: Rated voltage ≥ 100V, rated current ≥150A
- 2、Power grid side AC circuit breaker parameters recommended: rated voltage ≥500V, rated current ≥50A
- Back-up AC circuit breaker parameters recommended: rated voltage ≥500V, rated current ≥30A
- 4. Diesel generator side AC circuit breaker parameters recommended: rated voltage ≥500V, rated current ≥50A

Ac circuit breaker Ground Grid screw Ac circuit breaker Dc circuit breaker Ac circuit breaker CT installation ! ! !! direction ilnverter-> Gridi AC Load BAT Back-up Load PV generator

Figure 6.1 Electrical connection diagram

Note: During final installation, circuit breakers for external connections to the inverter shall comply with IEC 60947-1 and IEC 60947-2 certification requirements.

# **6.2 External Port Wiring Instructions**

**Table 6-1 Cable Model and Specification Descriptions** 

Table 6-1 Cable Wodel and Specification Descriptions				
Port	Definition		Cable type	Cable
				specification
		nect		Recommended
	to PV			6mm²
	positive	pole	Outdoor	cross-sectional
PV1 PV2 PV3		4	Multi-Core	area of
	-: Conn	ect	Copper	conductor,
	to PV		Cable	maximum
	negativ	е		current through
	pole			the wire is 30A
				Recommended
	+: Connect to battery positive pole Outdoor Multi-Core -: Connect to battery negative Cable			35mm²
\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$				cross-sectional
				area of
				conductor, the
			maximum	
			Cable	current through
				the wire shall
	pole			be 150A
				Recommended
3 9 1		L1		6mm²
	AC		Outdoor	cross-sectional
load port		L2	Multi-Core	area of
			Copper	conductor,
		L3	Cable	maximum
				current through
BAGK-UP	N			the leading wire

_				
		PE		is 30A, grounding cable specifications are the same as the phase conductor
gri		L1		Recommended 8mm <sup>2</sup>
		L2		cross-sectional area of
	AC	L3 Outdoor Multi-Core	conductor, maximum current through	
	grid port	N	Copper Cable	the wire is 50A, grounding
		PE		cable specifications are the same as the phase conductor
		L1		Recommended 8mm²
	AC	L2	Outdoor  Multi-Core  Copper  Cable	cross-sectional
	port	L3		conductor,
		N	Cable	current through
GEN		PE		the wire is

	50A, grounding
	cable
	specifications
	are the same
	as the phase
	conductor


# 6.3 Connecting the Ground Cable (PE)




Since the inverter is a transformer-less type, it is required that the positive and negative electrodes of the photovoltaic array cannot be grounded, otherwise the inverter will fail. In the photovoltaic power system, all non-current-carrying metal components (such as brackets, distribution cabinet enclosures, inverter enclosures, etc.) should be connected to the ground.

# Figure 6.2 Schematic diagram of protection grounding

For yellow-green outdoor cables, use a wire stripper to strip the insulation layer of the ground cable to an appropriate length. Insert the wire core stripped of the insulation layer into the conductor crimping area of the OT terminal, and press it tightly with wire crimping pliers.





# 6.4 Connecting the PV Cable and the Battery Cable

# Danger

### PV series connection:

- Do not connect the same PV series to multiple inverters. Otherwise, the inverters may be damaged.
- Before connecting the PV series to the inverter, confirm the following information. Otherwise, the inverter may be permanently damaged or fire may occur, which may cause personal and property loss.
- Ensure that the maximum short circuit current and maximum input voltage of each PV are within the allowable range of the inverter.
- Ensure that the positive terminal of the PV string is connected to the PV+ of the inverter, and the negative terminal of the PV string is connected to the PV- of the inverter.



### PV series connection:

The PV string output does not allow for grounding. Before connecting the PV string to the inverter, ensure that the minimum insulation resistance to the ground of the PV string meets the minimum insulation impedance requirement..

### NOTE:

- 1.Before crimping the PV cables, ensure that the PV knob switch is set to OFF and the battery is powered off.
- 2. The photovoltaic module used to connect to the inverter should meet the IEC 61730 certification of grade A standard requirements, each photovoltaic series and battery input from the external circuit breaker allowed through the maximum current should be more than or equal to 30A.


Remove the connector rear cover

Waterproof rubber ring Nut

Route the stripped DC cable through the nut and waterproof rubber ring

7-8mm

28



# 6.5 Connect battery cable

# **A** Danger

# Battery cable connection:


- A battery short circuit may cause personal injury. However, a short circuit may release a large amount of energy, which may cause fire.
- > Before connecting the battery cable, ensure that the inverter and battery are powered off, and the front and rear switches of the device are off.
- Do not connect or disconnect battery cables when the inverter is running. Improper operations may result in electric shock.
- Do not connect the same battery string to multiple inverters. Otherwise, the inverters may be damaged.
- > Do not connect loads between the inverter and the battery.
- When connecting battery cables, use insulation tools to prevent accidental electric shock or battery short circuit.
- Ensure that the open circuit battery voltage is within the allowable range of the inverter.



### **Battery cable connection:**

- When connecting cables, the battery cable matches BAT+ and BAT- on the battery terminal.
- Ensure that the cable core is fully connected into the wiring hole of the terminal.
- Ensure that the cables are securely connected. Otherwise, the terminal may overheat and damage the device.


Figure 6.4 Connecting Battery cables




The maximum current allowed to pass through the circuit breaker used for external connection of batteries should be greater than or equal to 150A

# 6.6 Connect AC Load/grid/Diesel generator Cable

Figure 6.5 Connecting AC load/grid/Diesel generator cables





The maximum current allowed through the circuit breaker for off-grid load to the external connection should be greater than or equal to 30A.

The maximum current allowed through the circuit breaker for grid or Diesel generator to the external connection should be greater than or equal to 50A.

# 6.7 Installation of Communication Dongle

The communication collector is an external component that you need to select by yourself.

The collector is connected. The default WIFI/ Bluetooth module is used for remote monitoring and control of the inverter.

Install Dismantle

Figure 6.6 Communication interface and installation and disassembly diagram

Table 6-2 Indicators on the AGN8 WIFI Dongle

LED	state	Specific meanings	
	Alternating flashing (cycle 1500ms, each light flashes for 500ms in sequence)	Self test mode	
RUN&COM&NET	Floobing to gother (evolod account off 000mg an	Dongle is currently	
	Flashing together (cycle 1 second, off 900ms, on	upgrading (including	
	100ms)	Bluetooth App upgrade)	
	Illuminate together for 5 seconds	Dongle upgrade failed	
RUN	Slow flashing (on for 1 second and off for 1	Dongle is running	
	second)	normally	
	Limba off	Dongle running	
	Light off	abnormally	
	Twice flashing (on (off) 100ms, off (on) 100ms,	Dongle sends Bluetooth	
	twice)	data to the app	
сом		Dongle time not	
	Flash (on for 200ms, off for 200ms)	synchronized (scanning	
		will not start)	
	limbs off	Abnormal southbound	
	Light off	communication	
	Flashing once (on (off) 100ms, off (on) 100ms,	Normal southbound	
	once)	communication	
NET	Flash	Connecting to WiFi	
	Light off	Connecting to MQTT	
	Slow flashing	Connecting to platform	
	Alversa	Successfully connected	
	Always on	to the platform	
	Total floation	Dongle sends platform	
	Twice flashing	data	

Table 6-3 Meaning of AGN9 4G Dongle indicator light

LED	state	Specific meanings
RUN&COM&NET	1	1
	Alverse on	The process from power
	Always on	on to initialization
		Gateway initialization
RUN	Flash (with an interval of 100ms)	completed, flashing for 5
		seconds
	Twice flashing (on (off) 100ms, off (on) 100ms,	Slow flashing (with an
	twice)	interval of 1 second)
СОМ	1	1
	Ab.,,,,,	Looking for the internet
	Always on	or on a call
		Data connection
	Flash (interval 200ms)	established or network
NET		registered
	Claus flacking (with an interval of 000mg)	2G/3G network
	Slow flashing (with an interval of 800ms)	registered
	light off	Shutdown or module
	Light off	sleep

### 6.8 Connecting the Communication Port

Multifunctional communication port, including meter communication, BMS communication, DRMS, parallel communication and external dry contact signal.

**Step 1:** Route the communication cables through the waterproof cover and waterproof plug of the signal port, and connect the cables to the communication port on the corresponding device.

Step 2: Fasten the waterproof cover with screws and tighten the waterproof nut.




Figure 6.7 Interface diagram




Table 6-4 Port description

PIN Definition	
2011	Function of heat pump/diesel generator
CON	multiplexed DO&DI interface
METER	Electric meter communication interface
BMS1	BMS1 CAN port &EMS RS485 multiplex port
BMS2	BMS2 CAN port &EMS RS485 multiplex port
	DRMs/ diesel generator/lead-acid battery
DRM	temperature sampling function multiplex
	interface

PARA1	Parallel communication interface
PARA2	Parallel communication interface

Figure 6.8 Sequence of RJ45 crystal terminals




Table 6-5 RJ45 cable sequence colors

1	2	3	4	5	6	7	8
Orange	0	Green&	Divis	Blue&	0	Brown&	D
&White	Orange	White	Blue	White	Green	White	Brown

#### 6.8.1 Smart Meter Connection

L1, L2, L3, and N on the meter are respectively connected to L1, L2, L3, and N of the power grid.

The current measurement needs to be connected with the current transformer. I1+ and I1- on the meter are connected to the positive and negative leads of the current transformer respectively, and then the current transformer is connected to the L1 phase of the power grid. Similarly, I2+ and I2- connect to the current transformer and connect to the L2 phase, and I3+ and I3- connect to the current transformer and connect to the L3 phase. EP+ and EP- are institutional verification ports. Users do not need to access these ports. The wiring diagram is shown in Figure 6.9. (For the system power distribution diagram, refer to Figure 6.1 Electrical connection diagram.)


RS485

| Compared to the content of the content of

Figure 6.9 Smart meter terminal wiring diagram

The grooves of the current transformer have arrows for current flow, as shown in Figure 6.7. The tip of the arrows points to the power grid.

Figure 6.10. Direction of current transformer cable



According to Table 6-6, connect ports 8 and 7 of the RJ45 cable terminals on the METER corresponding to RS485-A and RS485-B on the meter corresponding to Figure 6.10.

Table 6-6 Smart meter interface description

PIN	Colour	Definition	Function	Note
1-6	/	1	1	/
7	Brown& White	RS485_B-EEM	RS485 differential signal B	Smart meter
8	Brown	RS485_A-EEM	RS485 differential signal A	485 communication

### 6.8.2 BMS Communication Connection

#### Table 6-7 Description of BMS1 ports

Table 6-7 Description of Dinot ports				
PIN	Color	Definition	Function	Note
	Orange &	D0405 A4 D140	RS485 differential	
1	White	RS485-A1-BMS	signal A1	
•		D0405 D4 D140	RS485 differential	
2	Orange	RS485-B1-BMS	signal B1	BMS1 CAN port
3	,	,	,	&EMS RS485
	,	,	,	multiplex port
4	Blue	CANA-H1-BMS	CAN high level data	
_	Blue&			
5	White	CANA-L1-BMS	CAN low level data	
6	C	CNID	CND	CNID
6	Green	GND	GND	GND
7~8	/	/	/	

### Table 6-8 Description of BMS2 ports

			·	
PIN	Color	Definition	Function	Note
1	Orange &	RS485-A2-BMS	RS485 differential	BMS1 CAN port
1	White	NO400-AZ-DIVIO	signal A2	&EMS RS485

2	Orange	RS485-B2-BMS	RS485 differential	multiplex port
3	/	1	1	
4	Blue	CANA-H2-BMS	CAN high level data	
5	Blue& White	CANA-L2-BMS	CAN low level data	
6	Green	GND	GND	GND
7~8	1	1	1	

Note: Communication with lithium batteries requires attention to the battery's communication port sequence and pin definition.

### 6.8.3 DRMS/DI Connection

Table 6-9 Description of DRM ports

PIN	Color	Definition	Function	Note
	Orange	DDM4/5	① The DRMS interface is	
1	&White	DRM1/5	applicable to the Australian	
2	Orange	DRM2/6	AS-NZS-4777.2 (some	DRMs/diesel
	Green&	55140/5	European requirements)	generator/lead-acid
3	White	DRM3/7	safety standard	temperature
4	Blue	DRM4/8	②Diesel generator function	sampling function
_	Blue&	DEE 051	DI input	multiplexed port
5	White	REF GEN	③Lead-acid battery	
6	Green	COM LOAD	temperature sampling	
	Brown&	,	,	,
7	White	/		/
8	Brown	1	/	/

NTC connection for lead acid battery:

- ① Cut one end of the standard network cable
- 2 Strip the green, green&white, and blue wires at the fracture by 5mm
- ③ Weld it together with the NTC pin as shown in the following figure (After confirming that the welding is solid, wrap the welding place with insulation tape respectively, pay attention to avoid contact with bare metal, prevent short circuit, and affect normal use)
- ④ Insert the finished NTC crystal head into the DRMS connector, and attach the NTC to the outside of the lead battery




Table 6-10 Description of dry contact ports

	PIN	Definition	Note
50.4	2	OP1_NO	
DO 1	4	OP1_COM	External dry contact
	1	OP2_NO	port
DO 2	3	OP2_COM	
/	5-6	1	1

#### 6.8.4 Paralleling


If multiple inverters are used, connect the terminal of the network cable to Pa1 of the first inverter, connect the other end to Pa2 of the second inverter, and so on. Table 6-11 describes the signal of the network cable. Figure 6.11 shows the sequence of the network cable connection.

Table 6-11 Description of parallel ports

PIN Colour PARA 1	PARA 2	Note
-------------------	--------	------

1	Orange & White	CON1_AO	CON2_AO	
2	Orange	CON1_BO	CON2_BO	
3	Green& White	CON1_AI	CON2_AI	Parallel signal
4	Blue	CON1_BI	CON2_BI	
5-6	1	1	1	1
7	Brown& White	CON_SyncH	CON_SyncH	Simultaneous
8	Brown	CON_SyncL	CON_SyncL	signal


Figure 6.11 Parallel communication line sequence diagram



### Application note:

- Supports a maximum of 6 three phase hybrid inverters in parallel;
- Ensure that the inverters are connected to parallel lines;
- Ensure that the load power is less than the maximum parallel power.
- The length of the cable connecting the load end of the inverter to the BACK UP end of each device must be the same to ensure loop impedance;

Parallel standard wiring is shown in the following figure, detailed operation see parallel system operation manual.



## 7 Inverter Operation

### 7.1 Pre-power-on Inspection

Serial	Check the entry
1	The inverter is firmly fixed to the mounting bracket on the wall.
2	Cables are bundled according to cable routing requirements, properly distributed, and without damage.
3	PV+/PV-, BAT+/BAT- cables are firmly connected, the polarity is correct, and the voltage is within the accessible range.
4	The DC switch is properly connected between the battery and the inverter, and the DC switch is off.
5	The AC circuit breaker is correctly connected between the inverter port and the power grid, and the circuit breaker is disconnected.
6	The AC circuit breaker is correctly connected between the inverter load port and the power grid, and the circuit breaker is disconnected.
7	For lithium batteries, ensure that the communication cables are properly connected.

#### 7.2 Initial Power-on

Follow these steps to turn on the inverter

- 1) Ensure that the inverter is not working;
- 2) Close the AC circuit breaker between the inverter On Grid port and the Grid;
- 3) Turn on the PV DC switch on the inverter (when connected to PV);
- 4) Turn on the battery and close the DC switch between the battery and the inverter;
- 5) The inverter starts to run after the self-test is successful;
- 6) Close the AC circuit breaker between the inverter Back up port and the load.

### 7.3 Working Mode


#### 7.3.1 Self-use Mode (default mode)


#### **Function:**

Give priority to the use of photovoltaic and battery energy, as far as possible not to use the energy of the grid. Photovoltaic energy is priority to supply loads, excess energy to charge the battery, and finally the remaining energy is fed to the grid.

#### Specific working mode:

- When the PV is sufficient, the PV prioritizes supplying power to the load, charging the battery with excess electricity, and the remaining electricity can be feedback to the grid.
- When the PV is insufficient, the PV and battery supply power to the load.
- When the PV and battery are insufficient, the PV, battery, and power grid work together to supply power to the load.
- When the PV is not working and the battery is sufficient, the battery supplies power to the load
- When the PV is not working and the battery is insufficient, the battery and the grid work together to supply power to the load.
- When the PV and battery are not working, the power grid supplies power to the load, forming a bypass output.
- When the power grid is unable to supply power, the photovoltaic and battery jointly power the load.





### 7.3.2 Timed Charge/Discharge Mode

#### Function:

Set the charge and discharge period and power based on user requirements. For example, when the electricity price is high during the day, set discharge, and the electricity of batteries and photovoltaic is used to power the load; Set charging at night when the electricity price is low, and the electricity of the grid is used to charge the battery, so as to achieve the role of peak cutting and valley filling.

#### Specific working methods:

#### Charging time period:

- When the PV is sufficient, the PV charges the battery, and the remaining electricity supplies power to the load.
- When the PV is insufficient, the photovoltaic and grid work together to charge the battery and supply power to the load.


• When PV is not working, the grid charges the battery and supplies power to the load.

#### Discharge time period:


- When PV is sufficient, PV supplies power to the load.
- When the PV is insufficient, the PV and battery supply power to the load.
- When the PV is not working and the battery is sufficient, the battery supplies power to the load.
- PV does not work, and when the battery is insufficient, the battery and grid supply power to the load.
- When the PV is not working and the battery is not working, the grid supplies power to the load

Note: The charging power is defined as the power of the inverter to charge the battery, and the discharge power is defined as the power of the inverter output.

#### Charging period:



### Discharge period:




#### 7.3.3 Backup Mode/Disaster Recovery Mode


#### Function:

When connected to the grid, the battery is always kept in a fully charged state to cope with sudden grid outages or other emergencies (photovoltaic and grid energy give priority to charge battery, excess energy to meet the load power supply needs, and finally the remaining energy is fed to the grid), so as to ensure that users can use the battery storage power to supply power to the load after an emergency (off-grid state) to avoid the situation of no power available.

### Specific working mode:

- When PV is sufficient, PV prioritizes charging the battery before supplying power to the load, and the remaining electricity can be fed back to the grid.
- When PV is insufficient, the PV and the power grid charge the battery first, then supplies power to the load.
- When PV is not working, the grid charges the battery and supplies power to the load.
- When the power grid is unavailable, the PV and battery supply power to the load.






#### 7.3.4 Priority Feed to Grid Mode

#### **Function:**

After meeting the load power consumption, excess photovoltaic energy is priority feed to the grid. Photovoltaic energy is given priority to meet the load power supply needs, followed by excess energy is fed to the grid, and finally the remaining energy is charged to the battery.

### Specific working mode:

- If sufficient PV is generated, the PV supplies power to the load first and then to the grid. The remaining power (the part where the PV power exceeds the inverter power) can be used to charge batteries.
- The other cases are in the same self-use mode.



## 7.4 Operation Mode

### 7.4.1 Operation Mode Description

Table 7-1 Inverter operating modes

	Table 7-1 inverter operating modes						
Series No.	Mode	Description					
		Waiting phase after the inverter is powered on.					
1	Standby	Enter the self-check state when the conditions are met.					
		If a fault occurs, the inverter enters the fault state.					
		Before the inverter starts, continue to self-check and initialize.					
		If the conditions are met, the inverter enters the grid-connected					
	Self-check	state and starts grid-connected operation.					
2	mode	If no power grid is detected, the inverter enters the off-grid state					
		and runs off the grid.					
		If the self-check fails, the system enters the fault state.					
		The inverter is connected to the grid normally					
		If it is detected that the power grid does not exist or the conditions					
		do not meet the requirements for grid connection, it enters the					
		off-grid working state.					
		If a fault is detected, the system enters the fault state.					
3	On-grid mode	If the power grid conditions do not meet the grid-connection					
		requirements and the off-grid output function is not enabled, the					
		system enters the waiting state.					
		If after switching off the grid, it is detected that the grid conditions					
		meet the grid-connected requirements, and the grid-connected					
		function is enabled, it enters the grid-connected state					
		When the power grid is powered off or the grid conditions do not					
	O#i-l !	meet the grid-connected requirements, the inverter switches to the					
4	Off-grid mode	off-grid state and continues to supply power to the loads.					
		If the grid conditions meet the grid-connected requirements, the					

		system enters the grid-connected state .
		Before running, the inverter works off the network when the working
		mode is set to off-network mode.
		If a fault is detected, the device enters the fault state.
5	Fault mode	If a fault is detected, the inverter enters the fault state. After the fault
	7 auit mode	is rectified, the inverter recovers to its original running state.

### 7.4.2 Indicator Light Description

The bar indicator in the middle of the device panel indicates the inverter status in red, green, and blue colors.

**Table 7-2 Indicator status description** 

Display item	Indicator light status	Corresponding status description	Notes
Green	Always on	Grid connection	Indicates that the inverter is currently working in a grid connected state and can exchange energy with the power grid.  The load can be powered on for operation.
	Flashing 1s/time	Be ready	Indicates that the inverter is in the power-on state and needs to wait until the power-on is completed before the load can be powered on and run.

			Indicates that the
			inverter has just been
			powered on and the
		The inverter has	program initialization
		just been powered	will flash for 10s;
	Flashing	on and the	Indicates that the
	0.1s/time	program is	current working status
		initialized/Code	is in shutdown state,
		online upgrade	and it can be turned
			on and used normally
			after the code
			upgrade is completed.
			Indicates that the
			inverter is currently
Dive			working in an off-grid
Blue		Off	state and cannot
	Always on	Off-grid	exchange energy with
			the power grid. the
			load can be powered
			on and run.
			Indicates that the
			inverter is currently in
Red			shutdown state, a
	Always on	System error	serious alarm occurs
			on the inverter, and
			the load cannot be
			powered on and run.

			Indicates that the
			inverter is currently in
			shutdown state, a
	Flashing for	System arror	relatively serious
	0.5s/time	System error	alarm has occurred
			on the inverter, and
			the load cannot be
			powered on.
			Indicates that the
			inverter is currently in
	Flashes		shutdown state, an
	2s/time	System error	alarm occurs on the
			inverter, and the load
			can't be powered on.

## **8 App Introduction**

Users need to choose WiFi dongle or 4G dongle.

ESS LINK Operation and use Please contact the manufacturer and check the ESS LINK operation and use manual.

Android version: Please scan the QR code below to obtain.

IOS version: Please scan the QR code below to obtain or go to the App Store search ESS LINK to download.



Android apk



Google play



iOS

# 9. Troubleshooting and Maintenance

This section will help you determine the cause of the problem you may be experiencing.

### 9.1 Alarm and Processing

Faults not mentioned in the following table still exist after being powered on. Contact vour dealer or after-sales service center.

your dealer or alter-sales service center.					
Sequence number	Fault name	Note	Solutions		
			PV		
1	PV 1/2 is not connected	Remind	Check whether the PV 1/2 is correctly connected and whether the photovoltaic DC circuit breaker of the inverter is closed.		
2	PV 1/2 overvoltage	Fault	Check whether the PV series voltage is higher than the maximum input voltage of the inverter. If so, adjust the number of series PV modules and reduce the PV string voltage to fit the input voltage range of the inverter. After correction, the inverter will automatically return to the normal state.		
3	PV 1/2 overload time out	Alarm	Check whether the inverter is in the overload state. The alarm is automatically cleared 10 minutes after the inverter is normal or the command is sent to clear the fault.		
4	PV 1/2 reverse connection	Fault	Check whether the PV 1/2 positive and negative terminals are reversed, and then power on again.		
5	PV connection mode is incorrect	Alarm	<ul> <li>Check whether the PV connection mode set on the APP host is consistent with the actual PV connection mode.</li> </ul>		

7	PV1/2 power tube is faulty PV 1/2 soft start failure	Fault Alarm	Disconnect all AC and DC circuit breakers and close the disconnected circuit breakers after 5 minutes. If the fault persists, contact your dealer or after-sales service center.  Battery
8	Battery 1/2 is not connected	Remind	Check whether the battery overvoltage is inconsistent with the battery specifications.
9	Battery 1/2 overvoltage	Remind	Check whether the battery is correctly connected or the voltage is abnormal. If yes,
10	Battery 1/2 undervoltage	Remind	the alarm is automatically cleared or the fault clearing command is sent.
11	Battery 1/2 power is insufficient	Remind	
12	Battery 1/2 do not charge	Alarm	Check whether the battery SOC is too high or
13	Do not discharge battery 1/2	Alarm	too low. The fault is automatically rectified after the SOC returns to normal after the
14	Battery 1/2 discharge terminates	Alarm	battery is discharged or charged.
15	Battery is 1/2 full	Remind	
16	Battery 1/2 reverse connection	Fault	<ul> <li>Check whether the positive and negative battery 1/2 cables are reversed.</li> </ul>
17	Temperature of the lead-acid battery is abnormal	Alarm	<ul> <li>Use the thermal imager to check whether the temperature of the lead-acid battery is too high. The fault will be automatically rectified when the temperature of the lead-acid battery is reduced to normal temperature.</li> <li>Check whether the wiring sequence between</li> </ul>

			_	
				the NTC and the network cable is correct.
				Reinsert the network cable from the
				communication port.
	D-#		>	Check whether the battery connection mode
18	Battery connection	Alarm		configured on the APP host is consistent with
	mode is incorrect			the actual battery connection mode.
			>	Please check whether the maximum battery
				charging current and maximum battery
19	Battery 1/2 overload	Alarm		discharge current are set too high in the
	timeout			battery Settings of the APP, and reduce the
				values appropriately.
	Battery 1/2 power			
20	tube is faulty	Fault	>	Disconnect all AC and DC circuit breakers and
	Battery 1/2 soft			close the disconnected circuit breakers after 5
21	startup fails.	Alarm		minutes. If the fault persists, contact your
	Procedure	7		dealer or after-sales service center.
			Other	5
			>	If the alarm is occasionally reported, the
	Grid voltage anomaly	Alarm		power grid may be abnormal for a short time.
				The inverter will resume normal operation
22				after detecting that the power grid is normal,
				and no manual intervention is required.
			>	If the alarm is generated frequently, check
23				whether the power grid voltage frequency is
				within the allowable range. If yes, check
	Network frequency anomaly			whether the AC circuit breaker and AC cable
		Alarm		connections of the inverter are correct, and
				whether the power grid is powered off.
				If the power grid voltage/frequency is not
				ii tile power grid voltage/frequency is flot

			_	
				within the acceptable range, the AC
				connection is correct, but the alarm is
				repeated, please contact technical support to
				change the power grid overvoltage and
				underfrequency protection value.
	Power grid voltage			
24	reverse sequence	Alarm		
	Grid voltage is out of		>	Check the phase sequence, voltage, and
25	phase	Alarm		wiring of the power grid.
26	Neutral wire anomaly	Fault		
	Heat sink			
27	temperature is too	Fault	<b> </b>	Ensure that the inverter is installed in a place
	high			that is out of direct sunlight, and restart the
	Ambient temperature		1	inverter after the heat sink cools down to 60°C
28	is too high	Alarm		for 5 minutes.
	The inverter is		>	If the fault persists, contact your dealer or
29	overheated.	Alarm		after-sales service center.
	Procedure			
			>	Check the impedance of the photovoltaic
				string to the protected area. If the resistance
				value is greater than 33 k $\Omega$ , it is normal. If the
				resistance value is less than 33 k $\Omega$ , check the
				short circuit point and rectify the fault. Check
30	Insulation fault	Fault		whether the PGND cable of the inverter is
	modiation radit	Tuuli		correctly connected. If no alarm is generated,
				the system automatically clears the fault or
				sends a command to clear the fault.
			>	
				If it is confirmed that the impedance is indeed
			<u> </u>	lower than the default value in a cloudy and

			_	1
				rainy environment, reset the insulation
				impedance protection point.
			>	Please check whether the inverter is
				connected properly.
31	Leakage protection	Fault	>	Disconnect all AC and DC circuit breakers and
31	failure	rauit		close the disconnected circuit breakers after 5
				minutes. If the fault persists, contact your
				dealer or after-sales service center.
			>	Check whether the external fan is blocked.
			>	Disconnect all AC and DC circuit breakers and
32	Fan failure	Fault		close the disconnected circuit breakers after 5
				minutes. If the fault persists, contact your
				dealer or after-sales service center.
			>	Please contact your distributor or after-sales
33	Model capacity fault	Fault		service center to check whether the model
				capacity is set incorrectly in the APP.
			>	Turn off the AC circuit breaker on the power
	Islanding protection			grid and check whether the power grid quality
				is poor or abnormal.
34		Alarm	>	Disconnect all AC and DC circuit breakers and
				close the disconnected circuit breakers after 5
				minutes. If the fault persists, contact your
				dealer or after-sales service center.
			>	Check whether the battery is exhausted or the
35				power of the inverter is too large.
	Do buo undemielte :	Ea!4	>	Disconnect all AC and DC circuit breakers and
	Dc bus undervoltage	Fault		close the disconnected circuit breakers after 5
				minutes. If the fault persists, contact your
				dealer or after-sales service center.

Bad earth  Pault  Parallel communication alarm  Alarm  Alarm  Alarm  Bad earth  Alarm  Alarm  Bad earth  Alarm  Alarm  Alarm  Alarm  Bad earth  Alarm  Alarm  Alarm  Bad earth  Alarm  Alarm  Alarm  Alarm  Bad earth  Alarm  Alarm  Alarm  Alarm  Bad earth  Alarm  Alarm  Alarm  Alarm  Bancing in poor contact.  Check whether the experial display, check the parallel communication line sequence is correct; if the sequence is correct, remove and reinsert the network cable from the communication port to prevent poor contact.  Check whether the external fan of the inverter is blocked.  Whether the ambient temperature is too high.  Display only in parallel situations. Check whether the parameters related to parallel Settings in the App are set correctly.  Alarm  Check that the meter is connected correctly.  Check that the meter is connected correctly.  Check that the meter is connected correctly.  Please contact your distributor or after-sales service center to check whether the parameters in the APP are set correctly or the software version is upgraded				
Parallel communication line sequence is correct; If the sequence is correct; If the sequence is correct, remove and reinsert the network cable from the communication port to prevent poor contact.  The system runs derated  Alarm  The number of parallel modules is abnormal  The parallel module number is repeated  Parameters of parallel modules conflict  The meter is reversed  The meter is reversed  The electricity meter is connected abnormally  The DSP1/2 parameter Settings are faulty  Please contact your distributor or after-sales service center to check whether the parameters or the APP are set correctly or the	36	Bad earth	Fault	the inverter is damaged or the connection screws are not tightened, resulting in poor
The system runs derated  Alarm  Alarm	37		Alarm	parallel communication line sequence is correct; If the sequence is correct, remove and reinsert the network cable from the
parallel modules is abnormal  The parallel module number is repeated  Parameters of parallel modules Alarm conflict  The meter is reversed  The electricity meter is connected abnormally  The DSP1/2 parameter Settings are faulty  Parameter is Fault reversed  Parameters of Parallel modules Alarm abnormally  Parameters of Parameters of Parallel modules Alarm abnormally  Parameter is Fault Parameter is connected correctly.  Please contact your distributor or after-sales service center to check whether the parameters in the APP are set correctly or the	38	,	Alarm	is blocked.
The parallel module number is repeated  Parameters of parallel modules conflict  The meter is reversed  The electricity meter is connected abnormally  The DSP1/2 parameter Settings are faulty  Alarm  Parameters related to parallel whether the parameters related to parallel Settings in the App are set correctly.  Settings in the App are set correctly.  Settings in the App are set correctly.  Please contact your distributor or after-sales service center to check whether the parameters in the APP are set correctly or the	39	parallel modules is	Fault	
Parameters of parallel modules conflict  The meter is reversed  The electricity meter is connected abnormally  The DSP1/2 parameter Settings are faulty  Parameters of parameters of parameter set correctly. Alarm parameters in the APP are set correctly or the	40	·	Alarm	whether the parameters related to parallel
The electricity meter is connected correctly.  Alarm abnormally  The DSP1/2 parameter Settings are faulty  Fault Please contact your distributor or after-sales service center to check whether the parameters in the APP are set correctly or the	41	parallel modules	Alarm	Settings in the App are set correctly.
is connected abnormally  The DSP1/2 Please contact your distributor or after-sales service center to check whether the parameters in the APP are set correctly or the	42		Fault	
parameter Settings Fault service center to check whether the parameters in the APP are set correctly or the	43	is connected	Alarm	> Check that the meter is connected correctly.
45 The DSP/CPLD Fault software version is upgraded	44	parameter Settings	Fault	service center to check whether the
	45	The DSP/CPLD	Fault	software version is upgraded

	version is	
	Procedure	
	The communication	
46	between the DSP	Fault
46	The communication	Fault

Table 9-1 Alarm list and troubleshooting measures

## 9.2 Regular maintenance

## / Warning

- > Make sure that the inverter is disconnected from power.
- > Wear personal protective equipment when operating the inverter.

**Table 9-2 Maintenance Instructions** 

Maintenance content	Maintenance methods	Maintenance period
System cleaning	Check the heat sink, air inlet/outlet for foreign objects and dust.	1 time/half year~1 time/year
Turn the DC switch on and off 10  DC Switch times continuously to ensure proper  DC switch function.		1 time/year
Electrical connection	Check whether the electrical connection is loose, whether the cable appearance is broken, and whether there is copper leakage.	1 time/half year∼1 time/year

## 10. Technical Parameters

### **Table 10 Technical Parameters Description**

(If 5-12kw models have certification requirements, please contact the inverter manufacturer)

Product model	Isuna D5K-TL	Isuna D6K-TL	Isuna D8K-TL	Isuna D10K-TL	Isuna D12K-TL	
Battery parameter						
Number of battery input channels	2					
Battery type		Lithium battery/Lead-acid battery/Sodium battery				
Battery voltage range	30~60V					
Full load battery voltage range	48~60V	48~60V	48~60V	48~60V	48~60V	
Maximum charge and discharge current	52.5A/52.5A	62.5A/62.5A	85A/85A	105A/105A	125A/125A	
Peak charge/discharge current&duration	55A/55A (60s)	65A/65A (60s)	90A/90A (60s)	110A/110A (60s)	130A/130A (60s)	
Nominal charge/discharge power	5000W	6000W	8000W	10000W	12000W	
Communication Interface	Communication Interface RS485/CAN					
PV input parameters						

Number of PV input channels	3				
Maximum input power	10000WP	12000WP	16000WP	18000WP	18000WP
Maximum input power	(5000WP/5000WP)	(6000WP/6000WP)	(8000WP/8000WP)	(9000WP/9000WP)	(9000WP/9000WP)
Maximum input voltage	800V				
MPPT voltage range	130~800V				
MPPT full load voltage	130V~800V	130V~800V	160V~800V	180V~800V	240~850V
range	1300~8000	1300~8000	1600~8000	1807~8007	240~850V
Starting voltage	140V				
Rated input voltage	600V				
Maximum input current	20 \ \ \ 20 \ \ \ \ \ \ \ \ \ \ \ \ \ \				
per MPPT	20A/20A/20A				
Maximum short-circuit					
current per MPPT	24A/24A/24A				
MPPT quantity	3				
Maximum input strings per	1/1/1				
MPPT	1/1/1				
Backfeed current	0A				

		Parallel input and or	utput parameters		
Nominal output power	5000W	6000W	8000W	10000W	12000W
Maximum output power	5.5kVA	6.6kVA	8.8kVA	11kVA	13.2kVA
Maximum grid input power	10kVA	12kVA	16kVA	20kVA	24kVA
Maximum grid input current	15.1A	18.2A	24.3A	30.3A	36.4A
Maximum output current	8.3A	10A	13.3A	16.7A	20A
Nominal output current	7.5A/7.2A	9.1A/8.6A	12.1A/11.5A	15.1A/14.4A	18.2A/17.3A
Nominal voltage	3L/N/PE, 220V/380Vac, 230V/400Vac				
Grid voltage range	184~276V				
Rated grid frequency	50/60Hz				
Grid frequency range	45Hz~55Hz/55Hz~65Hz				
power factor	-0.8~0.8				
THDi(@Nominal power)	<3%				
Off-grid output parameters					
Nominal output power	5000W	6000W	8000W	10000W	12000W
Maximum output power	10kVA (60s)	12kVA (60s)	16kVA (60s)	20kVA (60s)	20kVA (60s)
Nominal output current	7.5A/7.2A	9.1A/8.6A	12.1A/11.5A	15.1A/14.4A	18.2A/17.3A

Maximum output current	15.1A	18.2A	24.3A	30.3A	30.3A	
Nominal output voltage	ut voltage 3/N/PE, 220V/380Vac, 230/400Vac					
Rated frequency	50/60Hz					
Thdu(@ linear load)	<3%					
On/off-grid switch-over						
<10ms						
		Diesel generat	or interface			
Nominal input power	5000W	6000W	8000W	10000W	12000W	
Maximum input power	10KVA	12KVA	16KVA	20KVA	24KVA	
Maximum input current	15A	18A	24A	30A	36.4A	
Nominal output voltage	3/N/PE, 220/380Vac, 230/400Vac					
Generator voltage range	185-276V (P2N)					
Efficiency						
European efficiency	97.70%					
Maximum efficiency	98.20%					
Maximum battery						
charge/discharge 97.80%						
efficiency	efficiency					
Protection						

DC Switch	Available			
Input reverse	Available			
Output overvoltage,	Available			
overcurrent, short circuit				
Anti-islanding	Available			
Residual current detection	Available			
Insulation resistance	Assettable			
detection	Available			
Overvoltage Category	DC:II ; AC:III			
Surge protection level	DC:II ; AC:III			
Battery input reverse	Available			
connection protection	Available			
Integrate AFCI	Optional			
PID repair circuit	Optional			
Routine parameters				
Weight	35kg			
Noise	<45dB			
Topology	isolation			

Working altitude	<4000m				
Derating Temperature	>40℃				
Ambient Temperature	-25℃~60℃				
Ambient Humidity	5%~95%				
Cooling method	Air cooling				
IP Degrees	IP65				
Dimensions	465*665*165mm				
Standby loss	<15W				
	Features				
DC terminal	MC4/busbar				
AC output terminal	5P connector				
interface	RS485/CAN/DRED/DO/Parallel port				
Human-computer	HE/LEDIADDAMIEMO/Dissassas				
interaction mode	H5/LED/APP/WIFI/4G/Bluetooth				
Scalability in Parallel	Command				
function	Support				
Standard Warranty	5 years				

Certification				
Safety regulations	IEC62109-1&2, IEC62040-1			
EMC EN61000-6-1, EN61000-6-2, EN61000-6-3, EN61000-6-4 EN 61000-4-16, EN 61000-4-18, EN 61000-4-29				
Grid	VDE-AR-N 4105;VDE 0126-1-1 EN 50549-1;G98,G100; CEI 0-21;AS/NZS4777.2 NRS 097-2-1; G99			