

SINEXCEL

isuna

ESS LINK CLOUD
Operation Instruction

catalog

1 Introduction to ESS LINK CLOUD	3
1.1 Website	3
1.2 Account Registration & Login	3
1.2.1 Register Account	3
1.2.2 Login	5
2 Home Page	5
3 O&M Provider Management	5
3.1 O&M provider List - Edit	6
3.2 O&M provider List - Relationship	6
3.3 O&M provider List - Reset Password	7
3.4 O&M provider List - Employee Account	8
3.5 O&M provider List - More	8
3.6 Create New Subordinate O&M provider Account	9
4 End-User Management	10
4.1 End-User List - Reset Password	10
4.2 End-User List - Family Group Management	10
4.3 End-User List - More	11
4.4 Create New User Account	12
5 Power Station Management	13
5.1 Site List - Edit	13
5.2 Site List - More	14
5.3 Add site / Device	14
5.4 Batch Import	15
6 Equipment Management	15
6.1 Device List	15
6.1.1 Device List - Set Up	16
6.1.2 Device List - Upgrade / Version Upgrade	17
6.1.3 Device List - Template Configuration	20
6.1.4 Device List - Timing	20
6.2 Alarm Log	21
6.3 Upgrade Logs	21

7 Function Management	22
7.1 API	22
8 Staff Management	22
8.1 Staff List	22

1 Introduction to ESS LINK CLOUD

ESS LINK CLOUD is a web-based backend platform for remote monitoring and upgrading of inverters. Common features include:

- Monitoring inverter system data, alarms, software versions, etc;
- Setting inverter parameters;
- Remotely upgrading inverter software;
- Creating and managing subordinate O&M provider accounts.

1.1 Website

China <https://admin.pqwisdomcloud.com/>

Europe <https://europe.pqwisdomcloud.com/>


Asia Pacific <https://asiapacific.pqwisdomcloud.com/>


North America <https://northamerica.pqwisdomcloud.com/>

1.2 Account Registration & Login


1.2.1 Register Account

Step 1: Click App Icon > Server Switch (Ensure it matches the Wi-Fi dongle server selection). On the login interface, select **Server Switching** in the top left corner and choose the nearest server based on the device's geographical location; **Language** in the top right corner allows you to select the language type.





Step 2: Register > Select Server > Enter Mobile Number/Email > Get Verification Code > Set Password > Register to complete new account registration. As shown below:




Step 3: After successful registration, please contact the manufacturer to grant O&M provider permissions to the account.

Note: If you already possess an O&M provider account, skip this step.


1.2.2 Login

Open the backend website URL corresponding to the account's server (**see 1.1**) in a browser, or after opening the webpage, select the server corresponding to the account, then enter the registered and authorized O&M provider account and verification code to log in.



2 Home Page

The home page dashboard displays information for all devices bound under this account, including total number of sites, number of online devices, power generation, etc.



3 O&M Provider Management



The O&M providers List displays all subordinate O&M provider accounts created under this account. Use the various filter boxes to search for subordinate accounts. Clicking an O&M provider name will jump to the list of all sites bound to that provider's account.

3.1 O&M provider List - Edit

Edit information for an existing subordinate O&M provider account. The provider account name itself cannot be modified.


3.2 O&M provider List - Relationship

View and modify the parent O&M provider account for this provider. View the list of subordinate O&M provider accounts created by this provider.





3.3 O&M provider List - Reset Password

If the password is forgotten, you can reset the password for this O&M provider account.



3.4 O&M provider List - Employee Account

Display the list of staff accounts created under this O&M provider account. You can also add new staff accounts with different permissions.



3.5 O&M provider List - More

Disable or delete subordinate O&M provider accounts created by this provider. (Disabled accounts still exist but cannot log in; Deleted accounts will be cancelled).

3.6 Create New Subordinate O&M provider Account

Click "Add" to create a new subordinate O&M provider account. Fill in the relevant account information and save.

Note: Enabling "Share all sites under this account with me" means all devices subsequently bound to this subordinate account will automatically be bound to its parent O&M provider account.

4 End-User Management

The User List displays all end-user accounts within sites bound under this account. Use the various filter boxes to search for user accounts. Clicking the number of sites will jump to the list of all sites bound to that user account.

User nickname	user account	Number of power stations	role	state	Registration time	operate
[blurred]	[blurred]	1	Ordinary users	normal	2025-08-07 01:58:51	reset password Family group management more
[blurred]	[blurred]	1	Ordinary users	normal	2025-08-04 02:37:28	reset password Family group management more
[blurred]	[blurred]	1	Ordinary users	normal	2025-08-02 03:50:24	reset password Family group management more
[blurred]	[blurred]	1	Ordinary users	normal	2025-07-24 01:59:12	reset password Family group management more

4.1 End-User List - Reset Password

If the password is forgotten, you can reset the password for this end-user account.

reset password

cancel save

4.2 End-User List - Family Group Management

View the list of family group members under an end-user account. You can also add new family members or disband this family group.

identity	member name	Relationship with Creator	Member account	Joined on	operate
creator	admin	creator	[blurred]	2025-08-06 17:58:51	

4.3 End-User List - More

Disable or delete this user account. (Disabled accounts still exist but cannot log in; Deleted accounts will be cancelled).

ESS LINK CLOUD

home page > List of operation and maintenance providers > User List

User: Please enter user nickname user: Please enter the user account search for reset

nickname account

+ newly added

User nickname	user account	Number of power stations	role	state	Registration time	operate
[blurred]	[blurred]	1	Ordinary users	normal	2025-08-07 01:58:51	reset password Family group management more
[blurred]	[blurred]	1	Ordinary users	normal	2025-08-04 02:37:28	reset password Family group management more
[blurred]	[blurred]	1	Ordinary users	normal	2025-08-02 03:50:24	reset password Family group management more
[blurred]	[blurred]	1	Ordinary users	normal	2025-07-24 01:59:12	reset password Family group management more

4.4 Create New User Account

Click "newly added" to create a new user account. Fill in the relevant account information and save.

Note: "Invitation Code" is optional. It is only required when a user creates a family group and wants to add a new user to that group automatically.

ESS LINK CLOUD


home page > List of operation and maintenance providers > User List

User: Please enter user nickname user: Please enter the user account search for reset

nickname account


+ newly added

User nickname	user account	Number of power stations	role	state	Registration time	operate
[blurred]	[blurred]	1	Ordinary users	normal	2025-08-07 01:58:51	reset password Family group management more
[blurred]	[blurred]	1	Ordinary users	normal	2025-08-04 02:37:28	reset password Family group management more
[blurred]	[blurred]	1	Ordinary users	normal	2025-08-02 03:50:24	reset password Family group management more
[blurred]	[blurred]	1	Ordinary users	normal	2025-07-24 01:59:12	reset password Family group management more



5 Power Station Management


The site List displays all sites bound under this account. Use the various filter boxes to search for sites. Clicking the number of devices will jump to the list of all devices bound to that site.



5.1 Site List - Edit


Edit an existing site in the list, including plant information, customization, and permission management.

Note: "Allow remote operation and maintenance by the trustee" can only be modified by end-user accounts; O&M provider accounts cannot modify this setting.




5.2 Site List - More

Delete this site or unbind the end-user account. (Deleting dissolves the site, and its devices can be re-bound to other plants; Unbinding allows the site to be bound to a different end-user account).



5.3 Add site / Device


Follow the same steps as in the APP to bind a new site or device to this O&M provider account.



5.4 Batch Import

Select the "Add new equipment" template to download. Fill in the Site code, Communication code, and Device Name for the devices you want to batch import into the corresponding columns of the spreadsheet. Upload the spreadsheet to bind multiple sites and devices to this account.

Select the "Existing power station" template to download. Fill in the site Code or Comm code for the devices you want to batch import into the corresponding column of the spreadsheet. Upload the spreadsheet to bind multiple sites to this account or bind multiple devices to the same site.



6 Equipment Management

6.1 Device List

The Device List displays all inverters bound under this account. Use the various filter boxes to search for devices.

Click the Comm code or SN to jump to view this device's measurement data, version information, and operation records.

Click the Bound site to jump to the list of sites this device is bound to.

Click the End-User Account to jump to the list of end-user accounts this device is


bound to.

6.1.1 Device List - Set Up


Access the inverter parameter settings page to modify inverter-related parameters. Functionality is the same as the APP.

6.1.2 Device List - Upgrade / Version Upgrade

Search for the Comm code of the device needing upgrade or find it in the device list. Select the device(s), then click "Upgrade" or "Version Upgrade" to perform the software upgrade operation.



On the device upgrade page, double-check that the Comm code and Model are correct. The upgrade page shows the device's current software version information.



During upgrade, after selecting the corresponding file type, the upgrade file name and remarks will be displayed. Choose the appropriate upgrade method and click "Start" to begin. The progress bar shows the upgrade status. Click "Cancel Upgrade" to terminate the operation. **Do not close this page during upgrade!**



Note:

WiFi upgrade method only supports **Whole Package**, first upgrade the WiFi software and then upgrade the rest of the files;

For on-grid inverters, other file types can be upgraded using Whole Package or Subcontracting (Whole Package is faster but requires better network quality; choose Subcontracting if network quality is poor);

For off-grid inverters, other file types can only be upgraded using **Subcontracting**;

When the file type is "BMS", the subcontract size can only be "128".



When the progress bar turns green and shows "Upgrade Success", the file has been successfully upgraded to the device.

When the progress bar turns yellow and shows "Upgrade Failed", the file was not upgraded to the device. Check the reason for failure in the Upgrade Logs and retry the upgrade.

ESS LINK CLOUD

home page List of power stations devices

upgrade

model: O-SOL-P Communication stick model: ESP32-C3-MINI Version type: standard

start Cancel upgrade

	file type	current version	Upgrade method	Subcontract size	file name	version	Document Remarks	Reason for upgrade	
<input type="checkbox"/>	ARM	V112.0.0	subcc	512				Enter	Not started
<input type="checkbox"/>	DCAC	V112.0.0	subcc	512				Enter	Not started
<input type="checkbox"/>	DCDC	V112.0.0	subcc	512				Enter	Not started
<input checked="" type="checkbox"/>	WIFI	122.0.0000	Whole	512	ESP32-C3-MINI-WIFI-CommDongleStick_V122.0.0000.0 bin	V122.0.0000		Enter	Upgrade Successful

ESS LINK CLOUD

search for reset

upgrade Template configuration timing

upgrade

model: O-SOL-P Communication stick model: ESP32-C3-MINI Version type: standard

start Cancel upgrade

	file type	current version	Upgrade method	Subcontract size	file name	version	Document Remarks	Reason for upgrade	
<input type="checkbox"/>	ARM	V112.0.0	subcc	512				Enter	Not started
<input type="checkbox"/>	DCAC	V112.0.0	subcc	512				Enter	Not started
<input checked="" type="checkbox"/>	DCDC	V112.0.0	subcc	512	O-SOL-P-Isuna12000SO_DCDC_APP_V112B0000 bin	V112		Enter	Upgrade failed
<input type="checkbox"/>	WIFI	122.0.0000	Whole	512				Enter	Not started


ESS LINK CLOUD

home page List of power stations devices Upgrade log

Equipment serial number Please enter the device serial number Equipment model Please select file type Please select belong to Please select


Upgrade method Please select search for reset

ID	Equipment serial number	Equipment model	file type	belong to	Version Type	VERSION	Upgrade method	Reason for upgrade	state	update time	Update duration
1		ESP32-C3-MINI	WIFI	standard	standard	V122.0.0000	Whole package		Upgrade Successful	2025-08-15 14:43:46	01 m 08 s
2		AGN8 WIFI	WIFI	standard	Manufacturer debugging 1	V1.0.41	Whole package		Upgrade Successful	2025-08-14 14:25:06	53 s
3		U-PH	DCDC	standard	standard	V000	Whole package		Upgrade Successful	2025-08-14 12:22:12	03 m 06 s
4		U-PH	DCAC	standard	standard	V000	subcontracting		Upgrade Successful	2025-08-14 12:13:53	07 m 58 s
5		EESE-B401-E063	WIFI	standard	standard	V025	Whole package		Upgrade Successful	2025-08-14 12:11:42	01 m 28 s
6		EESE-B401-E063	WIFI	standard	standard	V025	Whole package		Upgrade failed	2025-08-14 11:49:12	05 m 14 s




6.1.3 Device List - Template Configuration

If the historical data charts or operating status information displayed in the APP for an inverter do not match reality, it may be due to an unconfigured template. Click "Template Configuration" to reconfigure the template for the inverter.



6.1.4 Device List - Timing

If the time points in the historical data charts displayed in the APP for an inverter are inconsistent with the site's time zone (lagging or leading), it may be because the Wi-Fi dongle time is not calibrated. Click "Timing" to recalibrate its time.



6.2 Alarm Log

Displays alarm information for all devices bound under this account, including current and historical alarms. Use the various filter boxes to search for alarm information.

Click the Comm code or SN to jump to view this device's measurement data, version information, and operation records.

Click Solution to view how to handle this alarm.

Equipment number	SN	Alarm Number	Risk level	Alarm content	state	Start Time	End Time	time zone	operate
		0x1099	give an alarm	converter # Battery 2 is prohibited from charging	current	2025-08-15 12:26:33		GMT+03:00	Solution
		0x1097	give an alarm	converter # Battery 1 is prohibited from charging	current	2025-08-15 12:26:33		GMT+03:00	Solution
		0x1099	give an alarm	converter # Battery 2 is prohibited from charging	current	2025-08-15 12:26:28		GMT+03:00	Solution
		0x1099	give an alarm	converter # Battery 2 is prohibited from charging	current	2025-08-15 12:26:28		GMT+03:00	Solution
		0x1097	give an alarm	converter # Battery 1 is prohibited from charging	current	2025-08-15 12:26:28		GMT+03:00	Solution
		0x1097	give an alarm	converter # Battery 1 is prohibited from charging	current	2025-08-15 12:26:28		GMT+03:00	Solution
		0x1048	give an alarm	inverter # Abnormal voltage in the power grid	current	2025-08-15 11:50:22		GMT+03:00	Solution
		0x1049	give an alarm	inverter # Abnormal power grid frequency	current	2025-08-15 11:50:22		GMT+03:00	Solution
				converter # Battery 2 reaches standby So					Solution

6.3 Upgrade Logs


View the upgrade records and results for all devices bound under this account, used for after-sales troubleshooting. Use the various filter boxes to search for upgraded devices.

ID	Equipment serial number	Equipment model	file type	belong to	Version Type	VERSION	Upgrade method	Reason for upgrade	state	update time	Update duration
1		ESP32-C3-MINI	WIFI	standard	standard	V122.0.000.0	Whole package		Upgrade Successful	2025-08-15 14:43:46	01 m 08 s
2		AGN8 WIFI	WIFI	standard	Manufacturer debugging 1	V1.0.41	Whole package		Upgrade Successful	2025-08-14 14:25:06	53 s
3		U-PH	DCDC	standard	standard	V000	Whole package		Upgrade Successful	2025-08-14 12:22:12	03 m 06 s
4		U-PH	DCAC	standard	standard	V000	subcontracting		Upgrade Successful	2025-08-14 12:13:53	07 m 58 s
5		EESE-8401-E063	WIFI	standard	standard	V025	Whole package		Upgrade Successful	2025-08-14 12:11:42	01 m 28 s
6		EESE-8401-E063	WIFI	standard	standard	V025	Whole package		Upgrade failed	2025-08-14 11:49:12	05 m 14 s

7 Function Management

7.1 API

If users want to store all device data under their account on another cloud platform, they can obtain the data via the API interface. This page provides interface-related information and protocols. Contact the manufacturer for more support to use this function.



8 Staff Management

8.1 Staff List

The Employee List displays all staff accounts created under this account. Use the various filter boxes to search.

ESS LINK CLOUD

home page

Operations and M...

End-user Manage...

Power station ma...

equipment manag...

Function manage...

Staff management

Employee ...

home page >

List of power stations >

devices >

Upgrade log >

Alarm Log >

API >

Employee List >

Asia Pacific server

English

account number

Please enter the user accou

search for

reset

+ newly added

account number	account type	Creation time	operate
No data available at the moment			