

ESS LINK How to Create or Delete Maintainer Accounts

1, Why need to add a new maintainer account

When your installer installs an inverter for the first time or needs to adjust an end-user's inverter, and he or she needs to use the advanced parameter setting function in ESS LINK, it is required that the account is an maintainer account.

2, How to add a new maintainer account





Open ESS LINK homepage, click My -> Maintainer Management->Click plus icon in the upper right corner -> New Account -> Enter maintainer information -> Submit.

Note:

1. The email address entered in the account needs to be real and can be used normally, after click get verification code, you need to find the verification code in the email address and enter it.

2. At the bottom line: Share All Devices In This Account With Me, after clicking this option, all the inverters bound under this account will be automatically bound to your account.

3. This method only works for unregistered accounts, and is not available for registered accounts.



3, How to delete a maintainer account

Open ESS LINK homepage, click My -> Maintainer Management->Click Delete this maintainer.

