

承 认 书

SPECIFICATION FOR APPROVAL

产 品 名 称：用户手册

产 品 品 牌：

物 料 编 码：A81151080

供 应 商 型 号：


版 本：A00

Installation Instructions


Three phase HV Off-grid Inverter -Isuna 10000TO-20000TO




This guide is only for step-by-step reminders during the installation process, please read the user manual in detail before installation




Mounting tools




Electric drill: for drilling holes in walls.




M6 screwdriver: Removal and installation of screws and wiring.




M4 screwdriver: Removal and installation of screws and wiring.




Removal tool: Remove and install the PV terminal.



Wire strippers: Strip wires.



Crimping pliers: Crimp PV, BAT cable wires.




Marker: Punch marking.




Tape measure: Measuring distances.




Electrical Connection Diagram







Installation of wall mounts and inverters



Connecting Protective Earth(PE)





Connecting PV & BAT



After hearing a click sound, gently pull the cable to check whether it is fastened



Connecting the Grid & BACK-UP Terminal



Install

Remove

Connecting the WIFI dongle



ESS Link Download



Android



Google play



iOS

Download the user manual for details:
www.sinexcel-isuna.com/Download/